Step 1 :Save the update pack to your cellphone

(No need open , just save) File Name “ XCMode3(OnFly).....200730_101828.bin “





Step 2: Connect the your phone to station wifi



Find the network of DUOSIDA_XXXX, enter the password: duosida@cp

Step 3 : Open the App



Click the screen to scroll down and refresh until the list of charge points appears. After successful activation, the circular and arc indicators of the charge point will turn blue

*2：If red appears here, please scroll down again to refresh

Step 4: Choose “Manual Upgrade Firmware” in App



Step 5: Select the files

(Saved in cellphone by 1st step “XCMode3(OnFly).....200730_101828.bin”）



Step 6 :Download the firmware



Step 7 :Restart when updating finished